

GlazeGuard

Porcelain & Ceramic Sealer

2-Part Formula Mixing Instructions

MIX RATIO

Gloss & Satin

Mix Ratio 3:A:1B by volume

Matte

Mix Ratio 2:A:1B by volume



STEP

1

POUR

Into Empty 5 Quart Container

STIR PART A separately for **1 minute** until smooth, uniform color and consistency




MIX RATIO

Gloss & Satin

Mix Ratio 3:A:1B by volume

Matte

Mix Ratio 2:A:1B by volume



STEP

2

MIX


Add Part B **slowly** and stir Part A & B together for 2 minutes

STEP

4

ADD REDUCER

Mix reducer in **slowly** for 1 minute. The reducer helps level the sealer



STEP

5

APPLY EVENLY

Use 3/8 inch Nap Non Shed Roller

NOTE: Product must be used within 60 minutes of mixing



STEP

3

WAIT

Let the mixed product rest together for 5 minutes



FINAL STEP

6

LET DRY

Allow at least 12 Hr for light traffic or 48 for heavy traffic



Still Need Help?
(888) 387-2059



More info @

covertecproducts.com



Click To See
[Video](#)

IMPORTANT NOTES: Mix only enough material that can be used (applied) in 60 minutes

For best results, change out roller after 60 minutes of use



Application Instructions

Exterior /Wet Areas

BEGIN

The Brief

The surface must be properly prepared before applying GlazeGuard in outside areas and wet areas like restrooms and shower rooms. For long term results use 2 step cleaning process for surface preparation

use 2 step cleaning process for surface preparation

STEP 01

must be thoroughly cleaned with a high pH cleaner

Prepping of the Surface

Surface must be thoroughly cleaned with a high pH tile and grout cleaner like CoverTec CT50. Apply cleaner and scrub with a nylon grit brush. Allow 15 minutes for the substrate cleaner to breakdown grease deposits and soiling. Flood the floor with water and extract with a wet vac

STEP 02

Etch Surface

Apply PreTreat to microscopically etch the surface at a rate of 800- 1000 sq.ft per gal using a low pressure sprayer or mop. Caution use a spray devise that will not create heavy misting or over spray. The surface should be kept wet with the treatment (15 - 20 minutes)

apply PreTreat to microscopically etch the surface

Test product in an inconspicuous area before applying
(cover metal surfaces)

For Vertical Applications

For vertical applications like shower walls a second application is necessary. Reapply the second treatment after the first has dried out and allow to sit for 15 to 20 minutes and then rinsed away with clean, cold water. Scrubbing with a stiff wire brush or maroon scour pad may be necessary to remove heavy deposits of efflorescence or cement scale. Rinse thoroughly to remove residue and to ensure that it is pH neutral. If necessary neutralize the tile with neutral cleaner and squeegee off all excess of water. If no drains are available, use a wet-vac, then mop with fresh water. Allow the floor to dry before applying any subsequent floors sealer.



Application Instructions

Exterior /Wet Areas

STEP 03

Use Microfiber Mop

Vacuum up all the dust. Use a microfiber floor cloth to pick up any final dust and dirt.

make sure surface clear of any debris



Mix Part A with Part B and add Reducer

Use all mixed material within **60 minutes**

STEP 04

Mix Product Slowly

Stir Part A until smooth consistency. Pour Part A into mixing container adding Part B while mixing slowly for 2 minutes. Wait 5 minutes then add Reducer .

NOTE: If required slowly mix in *CoverGrip anti-slip additive (7.0 oz per gal) or it can be broadcast into GlazeGuard once applied to the floor while it is still wet.



Roll On Coating

Must use a non-shed 3/8 inch nap microfiber roller and 4 or 6" mini rollers for the edges. Remove fur from roller before use by rolling up and down on tacky side of blue tape.

Do not starve the roller of product 12 to 16 sq ft per dip. When rolling out the material do not push down too hard. Use the weight of roller to roll out any lines. Overlap and maintain wet edge (white).

STEP 05

For best results use roller tray to dip from

To avoid missed spots make sure the room is well lit



LET DRY



Dry time is 12 hours
Note: Varies based on temperature, humidity and environmental conditions



*CoverGrip clear white additive provides durable anti-slip floor in coatings and sealers.